


# Chain Link Gate Shut Installation



**1.** Remove top hinge from gate.




**2.** Remove chain link retainer.




**3.** Rotate Gate Shut spring onto top corner of gate.

### NOTE


To reverse the gate swing install spring with arm down onto top corner of gate.



*\*Spring arm must be on the same side as gate swings to work properly*



**4.** Insert spring into top right hole of front clamp piece and rotate into place.



**5.** Place back piece of clamp and install bolts finger tight.

**6.** Reinstall chain link retainer.

**7.** Reinstall top hinge on gate.



**8.** Adjust spring tension and tighten bolts.



**Final installed Gate Shut spring.**